GENT

by Honeywell

RESPONSE PAGING SYSTEM

PAGER USER GUIDE

FIRE SYSTEM **INNOVATORS**

GENT
by Honeywell

Turning On the Pager

Press and hold for 2 seconds, the pager will then display the standby screen.

After a short time the pager screen will go blank to preserve the battery, press any key to return to the standby screen.

Turning Off the pager

Go to the standby screen, press or keys to select the 'Turn Off' menu.

Press twice to confirm your choice.

Read Messages

To read a stored message, press from the standby screen.

Use or to scroll through the messages. Each message is allocated a slot number (i.e. 01, 02, 03 etc)

For messages that are longer than the two lines or to read the time and date of the message press

You will automatically return to the standby screen.

Deleting Messages

Display the message to be deleted, hold for 2 seconds to view the delete menu.

To delete a single message use the to select 'DEL', press to Confirm Delete Message.

To delete all Messages use to select 'D.ALL', press to Confirm Delete Message.

You will automatically return to the standby screen.

GENT
by Honeywell

Set Alert

From the standby menu press or to select the ‘Set Alert’ menu.

Press to confirm your option. Use the or to select option (Vibrate/Tone/Vibe & Tone/Silent)

Press to confirm your change.

Set Date & Time

From the standby menu press or to select the ‘Date & Time menu.

Press to confirm your option. Use the or to select correct data, press to confirm each selection.

Press to confirm your change.

Icons

Pager on

Low Battery

Message locked

Beeping Alert

Vibrate Alert

Unacknowledged message

Out of range indicator

Daily Alarm ON

Melody

Current message is a duplicate

Message continues on next page

Gent By Honeywell
140 Waterside Road,
Hamilton Industrial Park,
Leicester, LE5 1TN.

t 0116 246 2000
f 0116 246 2300
e gentenquiry@honeywell.com
www.gent.co.uk